

Mobile Radar

There is one mobile radar unit stored at the EVOC facility. The mobile radar is stored in the gravel lot to the south of Skills Pad “A”. The mobile radar is on caster wheels and can be pushed to anywhere around the EVOC facility. The mobile radar unit shall not be towed by a vehicle.



- To operate the mobile radar, turn the switch to the “On” position. The range of the mobile radar is about 800 feet. To prolong the life of the battery, the “On/Off” switch shall be turned to the “Off” position at the end of each training day.
- Always apply the wheel brake once the unit is positioned.



- Any agency/user utilizing the mobile radar unit, need to ensure that the unit is placed in an area where it does not pose a risk of damage or injury to any driver using the EVOC.
- The mobile radar unit must be returned to its storage location on Skills Pad A upon completion of the class. Always apply the wheel brake once the unit is positioned.
- Any damage or problems shall be reported to the EVOC facility director.